


Lista piese de schimb injector EASYFLOW



	Injectorul EasyFlow (complet, fara pozitiile 3.1, 8-11)	377740
1	Carcasa injectorului (fara pozitia 2)	377732
2	O-ring D16x2 mm	231517
3	Bucsa interna – Teflon	377724#
3.1	Bucsa interna – Sticla	377767#
4	Conexiune furtun	377716#
5	Piulita	377708
6	Supapa de sens-aer de transport (rosu-complet incl. pos. 6.1. si 6.2)	261211
6.1	Bila	240168
6	Arc	240176
7	Supapa de sens-aer suplimentar (negru-complet incl. pos. 6.1 si 6.2)	261203
8	Conector rapid (rosu) pentru furtun de aer de transport D8/6 mm	261645
9	Conector rapid pentru furtun de aer suplimentar D8/6 mm	261637
10	Furtun de plastic D8/6 mm (rosu)	103500*
11	Furtun de plastic D8/6 mm (rosu)	103756*
	Furtun de plastic 1104 – D16/11mm (standard)	103128*#
	Furtun de plastic 1105 – D20/11mm	100080*#

piesa de uzura

*specificati lungimea