


## **Lista pieselor de schimb pt. echipamentul de pulverizare – OptiFlex L**

1	Suport placa complet	385 190
2	Filtru complet (vezi lista de piese de schimb corespunzatoare)	
3	Unitatea de comanda CG07-complet(vezi manualul corespunzator)	
4	Rezervor (vezi lista de piese de schimb corespunzatoare)	
5	Pistol OptiSelect-complet(vezi lista de piese schimb corespunzatoare)	
6	Suport coloana complet	1002 532
7	Consola de montaj	1002 579
8	Cupla racord rapid-NW7,4-Ø10mm	239 267
9	Capac fix	364 720
10	Capac	364 010
13	Perie curatare-Ø12mm	389 765
14	Injector ( vezi manualul corespunzator)	
15	Racord rapid-aer transport (complet)	382 213
16	Racord rapid-aer suplimentar (complet)	382 221
23	Racord rapid aer fluidizare (complet)	382 230
25	Set piese, constand in:	1002 016
	Duza injector-teflon	377 724#
	Garnitura Ø 16x2mm	231 517#
	Siguranta F4.00AF	262 897
	Colier cablu L=100x2.5mm	200 719
26	Suport complet	1002 680
27	Instructiuni scurte pentru OptiStar CG07	1002 060
	Tabel programe pentru Optistar CG07	1002 063
	Cheie imbus nr.6	262 030
	Tub plastic-Ø8/6mm negru	103 152*

# Piese de uzura

\* Indicati lungimea

## Lista pieselor de schimb pt. echipamentul de pulverizare – OptiFlex L




OptiFlex L manual coating equipment - spare parts

## **Lista pieselor de schimb pt. echipamentul de pulverizare – OptiFlex L**

1	Suport pistol	1001 140
2	Cablu de alimentare	382 493
	Racord rapid-aer suplimentar(inclusive poz. 5,6,7)	382 221
5	Racord filetat - M12x1mm,Ø8mm	201 316
6	Furtun –Ø8/6mm,negru	103 756*
7	Racord rapid-NW5-Ø8mm,negru	261 637
	Racord rapid-aer transport (complet incl. poz.8,9,10)	382 213
8	Racord rapid-NW5-Ø8mm,rosu	261 645
9	Furtun negru 8/6mm,antistatic	103 500*
10	Racord filetat- M12x1mm,Ø8mm	201 316
11	Cablu pamantare-complet	301 140
12	Capac protectie	206 474
13	Surub –M8x12mm	263 214
14	Racord rapid	203 181
15	Furtun-Ø8/6mm,negru	103 756*
16	Racord filetat-M12x1mm,Ø8mm	201 316

\* Indicati lungimea


## Lista pieselor de schimb pt. echipamentul de pulverizare – OptiFlex L



## **Echipamentul de pulverizare OptiFlex L – rezervorul de fluidizare**

Rezervor – complet(inclusive pozitiile 1-21)	379 441
1 Corp rezervor	379 484
2 Suport placa	379 492
3 Saiba	382 191
4 Placa fluidizare	310 468
5 Capac	379 450
6 Suport sorb complet(inclusive poz.6.1	371 890
6.1 Garnitura-Ø28.3x1.78mm	261 564
7 Sorb L=233mm	371 939
8 Bucsa racord	379 468
9 Supapa-Ø0.7mm	371 904
10 Racord aerisire	377 988
12 Inel de strangere 160-05	258 237
13 Tampon de cauciuc-Ø15x8mm,M4/A	234 915
14 GarnituraØ15x1.5mm	261 564
15 Garnitura-Ø10.2/17x3.8mm	230 626
16 Surub cu cap inecat M5x16mm	262 986
17 Piulita PG29	262 056
18 Piulita PG21	234 869
19 Racord-NW5,1/8”I	200 859
20 Cot-1/8a-1/8a	1001 079
21 Garnitura cauciuc-10/4	379 441

## Echipamentul de pulverizare OptiFlex L – rezervorul de fluidizare



## **OptiFlex L – unitate de filtrare**

Unitate de filtrare – completa, fara pozitia 13

1001 147

1	Corp separator-F14MD	1001 759
2	Racord T-1/4”i-1/4”a-1/4”i	262 064
3	Racord cot-1/4”-Ø8/3x1mm	1002 614
5	Placa fixare	1001 758
6	Rezervor condens cu supapa de golire	1001 761
7	Cartus filtrant-20µm	1001 762
8	Surub-M4x60mm	258 946
9	Manometru-1/4”ext.Ø,0-10bar	1001 764
10	Racord-NW 7.4-1/4”a	256 730
11	Dop-Ø8mm	238 023
12	Cot-1/4”a-1/4”i	222 674
13	Racord rapid(pentru poz.10,nu este ilustrat)	239 267

